

TRENTON®

Corporate Office:
 The Trenton Corporation
 7700 Jackson Rd.
 Ann Arbor, MI 48103
 734/424-3600
 Fax: 734/426-5882

Houston Div./Export Office:
 1880 S. Dairy Ashford Rd.
 Suite 697
 Houston, TX 77077
 281/556-1000
 Fax: 281/556-1122

MC Outerwrap



Description:

MC Outerwrap is a specialized blend of quick curing resins impregnated into a fiberglass fabric. It provides soil stress and backfill protection to coatings that need additional mechanical strength. MC Outerwrap is specifically designed as a “hard shell,” UV stable outerwrap over the Wax-Tapes. It can also be used over other coatings. It is sold complete with gloves and Trenton End Adhesive. MC Outerwrap is hand applied, with no other application materials needed.

End Use:

MC Outerwrap is used aboveground or belowground as a mechanical protective wrapper over Trenton’s Wax-Tapes.

Application Procedures:

Pre-apply any of Trenton’s coatings and then, with only enough tension to keep the slack out, spiral wrap MC Outerwrap with at least a 50% overlap (use 80% overlap when needed in high stress areas such as transition pipe in clay soils). Make sure MC Outerwrap is extended out past the new coating on both ends for better anchoring. At the end of the last roll, brush on End Adhesive for MC Outerwrap to prevent possible unraveling before the wrap has cured.

Packaging:

Rolls are individually vacuum-packed in foil bags.
 4” x 12’ roll (4.0 sq ft / roll)
 4” x 27’ roll (9.0 sq ft / roll)
 6” x 27’ roll (13.5 sq ft / roll)
 9” x 40’ roll (30.0 sq ft/roll)
 NOTE: Alternative sizes may be available at an additional cost.

Specifications:

ColorBlack
 Average thickness 30 mil (when cured)*
 Application temperatures
 -20°F - 125°F(-34°C - 49°C)
 Pipe operating temperatures
 -30°F - 250°F(4°C - 121°C)**

* Thickness depends on amount of overlap.

** Trenton Wax-Tapes have a maximum operating temperature of 125°F

Advantages:

- Adds mechanical protection to soft coatings
- Superior protection against soil stress
- Protection against backfill
- A “hard shell” coating that may be painted

Estimate Quantity

Requirements:

1. Use seven as a 50% overlap factor for any width of MC Outerwrap.
2. Multiply seven times the actual OD of the coated pipe.
3. Divide that number by 100, which equals square yards per linear foot.
4. Multiply that number by the number of feet to be covered.
5. Divide that number by the amount of square yards per roll or case. (See Packaging, earlier, for quantity amount)